

Executive Order VR-102-A

Exhibit 1

Figure 1A

OPW Phase I Vapor Recovery System Equipment List

Component Name		Manufacturer	Model Number
Spill Containers and Covers¹	Figure 2E	OPW/POMECO	1-2100 Series 1C-2100 Series 1SC-2100 Series
Replacement Drain Valve Kit	Figure 2F	OPW	1DK-2100
Gasket Seal Adaptor	Figure 2G	OPW	FSA-400
Rotatable Phase I Adaptors	Figure 2H Figure 2I	OPW	61SALP-EVR (product) 61VSA-EVR (vapor)
Installation Tool	Figure 2J	OPW	61SA-Tool
Dust Caps	Figure 2K	OPW	634TT-EVR (product) 1711T-EVR (vapor)
Drop Tube Overfill Prevention Device²	Figure 2L	OPW	61SO-EVR Series
Jack Screw Kit	Figure 2M	OPW	61JSK-4400-EVR
Tank Bottom Protector	Figure 2N	OPW	6111-1400 (optional)
Tank Gauge Port Components	Figure 2O	Morrison Brothers	305XPA Series Tank Monitoring Cap and Ring Kit
Pressure/Vacuum Vent Valve	Figure 2P	Husky	Model 4885, 2-Inch Threaded

¹ The OPW/Pomeco 511 series covers include the 1-2100, 1C-2100 or 1SC-2100 spill containers.

² Ball float vent valves are not certified for installation of this system in new facilities (including those undergoing major modifications).